



Portal > FAQs > Internet Radios and Pure Connect / The Lounge > Binding your Reach F10 remote control

Binding your Reach F10 remote control

Pure Support - UK - 2014-06-18 - in Internet Radios and Pure Connect / The Lounge

How to bind the Reach F10 remote control to my Flow radio?

Your Flow Reach F10 remote control has an operational range of roughly 10 metres. If your remote only works in close proximity to the unit, does not bind or appears to be working erratically, please repeat the binding process as described in the instruction leaflet, replacing step 4 with the following process...

Open the battery compartment on the back of your remote. Located above the batteries is a small 'hardware bind' button. When prompted to press the Repeat + Shuffle buttons at the same time, press the hardware button instead (you will need a pen, or similar sized object for this). Continue by following the onscreen instructions on your Flow radio to complete the process.

For more detailed instructions on how to bind your remote control, check out our Step By Step guide to binding your remote - found here:

<http://support-uk.pure.com/kb/articles/238-binding-your-pure-remote-control-evoke-flow-av-anti-flow-and-sensia-only>