



[Portal](#) > [FAQs](#) > [Wireless Speakers](#) > [DiscovR](#) > [Privacy](#) > [How do I disable the microphones on my DiscovR speaker?](#)

How do I disable the microphones on my DiscovR speaker?

Pure Support-UK - 2019-06-03 - in [Privacy](#)

The microphones on DiscovR can be disabled in one of two ways:

- (i) Press the Mic mute icon on the control panel of your DiscovR speaker. Once the icon illuminates red, this indicates the microphones have been disabled.
- (ii) Press down on the top panel of the speaker until it closes to activate Mic Drop mode. This will disconnect and turn off the microphones for enhanced privacy.