



Portal > FAQs > All Other Radios > DAB Specific > How do I save pre-set 5 and above on the Pop Midi and Pop Midi Bluetooth?

How do I save pre-set 5 and above on the Pop Midi and Pop Midi Bluetooth?

Pure Support - UK - 2015-02-18 - in DAB Specific

To save a pre-set on pre-set number 5 you will need to be listening to the station that you want to save.

Press and hold **5+** until the screen says **store**. Then press **<or >** until you reach pre-set 5. You now **hold select** down for 3 seconds.

You will know the station has saved as the radio will say **pre-set stored**.

You can then repeat these instructions to save 6-10

To recall pre-set 5 and above

Tap **5+** once and scroll using **<or >** when you reach the pre-set station you would like to listen to press select.