



Portal > FAQs > Internet Radios and Pure Connect / The Lounge > The time is wrong on my Flow radio

The time is wrong on my Flow radio

Pure Support - UK - 2019-02-21 - in Internet Radios and Pure Connect / The Lounge

The time is wrong on my Flow radio

It's possible you have selected the wrong time zone when first setting up the radio - particularly if you're seeing the radio display incorrectly to the hour.

Adjust time zone on Evoke\ Avanti\ Oasis\ ONE Flow\ Contour and Siesta Flow radios:

Select '**Options > Alarm Timers > Select Time Zone**'

Adjust time zone for on Sensia:

Select the Clock on the bottom left hand corner of the screen and choose '**Zone**'.